MISTING WIZARDS

WHOLE-HOUSE AMBIENCE

MW-505

HVAC DIFFUSER

Professional HVAC-connected fragrance distribution designed for consistent ambience across expansive interiors.

- UP TO 8,000 SQ FT
- 500 ML CAPACITY
- ADJUSTABLE INTENSITY
- WALL MOUNT

DESIGNED FOR

Luxury residences • Hotel lobbies • Executive offices • Premium retail and hospitality interiors

WHOLE-SPACE FRAGRANCE. BEAUTIFULLY INTEGRATED.

PRODUCT SPECIFICATIONS

HVAC DISTRIBUTION • LARGE CAPACITY • ADJUSTABLE INTENSITY

SYSTEM PROFILE

MODEL	MW-505 Cube whole-house HVAC diffuser
COVERAGE	Up to 8,000 sq. ft.
CAPACITY	500 mL / 16.9 fl oz
CONTROL	Adjustable fragrance intensity
DISTRIBUTION	Connected to the HVAC system
INSTALLATION	Wall-mount configuration
ASSEMBLY	Two-piece diffuser and control system
CONSTRUCTION	Black housings with stainless accents

KEY BENEFITS

Expansive coverage

Designed to distribute fragrance through large HVAC-served interiors.

Custom intensity

Adjust output to suit the building, schedule and desired ambience.

Extended service

The 500 mL reservoir supports less frequent refilling.

Discreet integration

Wall-mount hardware keeps the system organized and serviceable.

APPLICATIONS

Whole-home fragrance • Hotel and resort common areas • Executive offices • Premium retail • Reception and hospitality spaces

PERFORMANCE NOTE

Actual coverage and fragrance perception vary with HVAC zoning, airflow, duct layout, ceiling height, occupancy, fragrance formulation, and selected intensity. Final placement and settings should be commissioned for the specific property.

Coverage and capacity are based on supplied product artwork; confirm final model documentation before publication.

HVAC INTEGRATION & SERVICE

DISCREET INSTALLATION FOR CONSISTENT WHOLE-SPACE AMBIENCE

TWO-PIECE PROFESSIONAL SYSTEM

Reservoir and atomizer assembly connect neatly to the separate control housing.

MULTI-ANGLE INSTALLATION REFERENCE

Wall brackets, service access, and connector orientation support a tailored installation.

1 Assess the HVAC

Confirm zones, return locations and airflow before placement.

2 Select the location

Use a secure, ventilated and accessible service area.

3 Mount both units

Fasten brackets to a suitable structural surface.

4 Connect carefully

Route the tube neatly and protect it from kinks or damage.

5 Commission output

Begin low and adjust gradually for even fragrance perception.

6 Maintain routinely

Inspect, refill and clean using approved fragrance media.

INSTALLATION NOTE

Installation should be completed by a qualified professional familiar with the property HVAC system. Use only approved fragrance media and follow model-specific electrical, ventilation, tubing, refill, and cleaning instructions.